

Polycom Studio USB Video Bar User Guide 1.0.0

Contents




Polycom Studio Remote Control

The Polycom Studio USB video bar provides a low-energy Bluetooth remote control, which automatically pairs with the USB video bar when you turn it on for the first time.

By default, Polycom Studio enables the Group Framing and Speaker-Tracking function, which provides hands-free experience except for basic buttons like volume, mute, answer, and hang-up.


The remote control sleeps if it's inactive for 30 seconds. You can press any key or move it to wake it up.



Button Icon	Button Name	Description
1	Volume Up/Down	Adjust speaker volume
2	Zoom In/Out	Adjust camera zoom in/out when the group framing and speaker-tracking mode is off
3	Camera Directions	Adjust the direction of camera when the group framing and speaker-tracking mode is off
4	Home	Resets the camera to its original status when the group framing and speaker-tracking mode is off
5	Preset 1/2	<p>Long press to store a camera setting</p> <p>Short press to load a camera setting</p> <p>The preset buttons only work when the group framing and speaker-tracking mode is off.</p>
6	Mute/Unmute	<p>Mutes or unmutes the microphone</p> <p>Long press the button to set the remote control ready for pairing.</p>
7	Bluetooth	Long press to enable other Bluetooth devices to find the Polycom Studio USB video bar
8	Group Framing and Speaker-Tracking	Enables or disables the group framing and speaker-tracking mode
9	Answer	Answers an incoming call
10	Hang Up	Hangs up a call



 as PDF Translate  s PDF

© 2020 Plantronics, Inc. Plantronics + Polycom NOW TOGETHER AS POLY

Site Map (<http://www.polycom.com/www-site-map.html>) Privacy Policy (<https://www.polycom.com/company/privacy.html>)

Terms of Use (<http://www.polycom.com/company/terms-and-conditions.html>) Trademarks (<http://www.polycom.com/company/trademarks.html>) Support (<http://support.polycom.com>)